


90 Day Ball Washer Maintenance

Overview: Range Servant Ball Washers are the most reliable in the industry; and virtually maintenance free. To preserve the integrity of every wash; take these simple steps every 3 months.

Tools Needed: 1 - 13mm Cresent Wrench or Socket Wrench, 1 - 6mm Allen Key

Step 1: Remove bin and the two 13mm bolts which secure the washer closed.



Step 2: Remove leaves, grass and other accumulated debris, comb the brush and rinse it clean.



Step 3: With washer open (and hands away from the inside of the washer and all moving parts) turn on the washer to confirm that water is freely spraying through both water nozzles. The main brush nozzle (figured left) is more important and should be spraying substantially more than the pre-spray (figured right). If the path of water looks disturbed, unscrew nozzle with a 6mm Allen Key to clean.







Remember Weekly: Pull out and dump debris from the Catch Drawer located underneath the washer.